



Looping Handle Wrap



1. Clamp it



2. Melt cord ends together



3. Twist clockwise



4. Wrap back to other side



5. Cover mending joint with first round, twist again



6. Continue to handle's end



7. Tie square knot, pass cord ends through hole



Done!